



When do you need a DC converter?

In practice, it appears that in less than 0.5% of the installed Tank-O3 systems, the water level meter interferes with the installation of the Tank-O3 system. Our advice: just install the standard Tank-O3 system, if necessary you can always order the DC converter!

DC converter to eliminate interference on water level meter.



Place the DC converter between the continuous current connection point you have found and the fuse, actually directly after the connection point, see diagram below.

